


## Head Body Separation Kit



- ① Head Mounting
- ② Conduit
- ③ Antenna Connection Box

### Note

- The Head Body Separation Kit is available in 3 lengths: 1m (3 ft), 2.5m (8 ft) and 10m (33ft).
- **The lengths of the conduit are not to be altered.** Altering the length of the cable will affect the performance of the scanner and will void the approval rating.
- The Kit can be connected to any standard 3DLevelScanner II.

Materials	
Housing	Painted aluminum die casting
Conduit	PA6
Ambient conditions	
Ambient, storage and transport temperature	-40...85°C (-40...+185°F)
Relative humidity	20...85%
Sealing	
Protection	IP67
CE	
EMC - Emission	EN 61326:1997 (class B)
EMC - Susceptibility	IEC / EN 61326:1997 + A1:1998 + A2:2001 + A3:2003
NSR (73/23/EWG)	EN 61010-1:2001


# Head Body Separation Kit

## Technical Data Sheet

**BINMASTER**

www.binmaster.com  
402-434-9102


### Head Body Separation Kit with 3DLevelScanner II



Dimensions in mm (inch)




**A** Place the flange onto the neck tube. Ensure that the O-ring on the neck tube remains in place for sealing.




**B** Remove the antenna connection box cover.



**C** Mount the box onto the scanner's neck tube. Note: the pin on the connection box must align with the groove on the neck.




Align the pin with the groove on the neck



**D**



Fasten




# Head Body Separation Kit

## Mounting Instructions


**E** Connect the scanner cable to the antenna connection box cable. Close the box cover.



**F** The Head Mounting part is supplied with the extension cable wired.



**G** Mount the Head Mounting part on a support or flange with 52mm hole for the neck. To avoid unnecessary damage to the cable, If the conduit is to be bend during installation, make sure that the radius of the bend is greater than 2.75" (70mm).



**H** Route the Conduit from the Head mounting part to the body in a secured path to avoid accidental damage.

**I** Continue the installation according to the instructions in the "APM Quick Installation Guide" manual.

# **BINMASTER**

Shipping Address: 7201 N. 98th St.  
Lincoln, NE 68507

Mailing Address: P.O. Box 29709  
Lincoln, NE 68529

800-278-4241 | 402-434-9102  
Fax: 402-434-9133  
www.binmaster.com  
info@binmaster.com